

# **Power Optimization of Gateworks Ventana 5200 board**

*A Project Report*

*submitted by*

**M SUDARSAN**

*in partial fulfilment of the requirements  
for the award of the degree of*

**BACHELOR OF TECHNOLOGY**



**DEPARTMENT OF ELECTRICAL ENGINEERING  
INDIAN INSTITUTE OF TECHNOLOGY, MADRAS.**

**April 2016**

# THESIS CERTIFICATE

This is to certify that the thesis entitled **Power Optimization of Gateworks Ventana 5200 board**, submitted by **M Sudarsan**, to the Indian Institute of Technology Madras, for the award of the degree of **Bachelor of Technology**, is a bona fide record of the research work carried out by him under my supervision. The contents of this thesis, in full or in parts, have not been submitted to any other Institute or University for the award of any degree or diploma.

**Dr. V Kamakoti**  
Research Guide  
Professor  
Dept. of Computer Science and Engineering  
IIT Madras, 600 036

Place: Chennai

Date:

## **ACKNOWLEDGEMENTS**

I would like to thank Dr. V. Kamakoti without whose constant support and motivation this project work would not have been possible. I would also like to thank Dr. Vasanth and Dr. Shankar for providing valuable technical support and guidance throughout the course of my project. Special thanks to all the network lab personnel for assisting me during my project work.

# TABLE OF CONTENTS

<b>ACKNOWLEDGEMENTS</b>	<b>i</b>
<b>LIST OF TABLES</b>	<b>ii</b>
<b>1 INTRODUCTION</b>	<b>1</b>
<b>2 Gateworks Ventana Board</b>	<b>2</b>
2.1 JTAG . . . . .	2
2.2 Bootloader . . . . .	2
2.3 Building images . . . . .	3
2.4 .config files . . . . .	5
2.5 TFTP server . . . . .	6
2.6 Firmware Installation via TFTP . . . . .	7
2.6.1 Power cycle . . . . .	8
2.6.2 Network configuration . . . . .	8
<b>3 Dynamic Voltage and Frequency Scaling</b>	<b>9</b>
<b>4 Interrupt Steering</b>	<b>11</b>
<b>A Loading Image</b>	<b>14</b>

## LIST OF FIGURES

2.1	menuconfig window . . . . .	5
3.1	Processor usage . . . . .	10

# CHAPTER 1

## INTRODUCTION

The GW5200 is a member of the Gateworks 5<sup>th</sup> generation Ventana family of network processor boards targeted for a wide variety of indoor and outdoor applications. The GW5200 features the Freescale™ i.MX6 Dual Core ARM® Cortex™-A9 SoC processor operating at 800MHz, 512Mbytes of DDR3-800 SDRAM, and 256Mbytes of System Flash. The Gateworks System Controller provides embedded features such as real time clock, voltage and temperature monitor, serial EEPROM, programmable pushbutton switch, and advanced power management with programmable board shut-down and wake-up for remote sensor applications. The Freescale™ ARM® Cortex™ A9 i.MX6 CPU includes many peripherals for supporting seamless voice, video, and data connectivity in small embedded applications. The overall system power consumption depends on both software optimization and how the system hardware is implemented. Since the hardware is fixed, the power consumption depends solely on software optimization.

## CHAPTER 2

### Gateworks Ventana Board

#### 2.1 JTAG

JTAG stands for Joint Test Action Group. JTAG Adapter is used for flashing firmware to Gateworks Boards as well as serial console access. JTAG USB is used to access Gateworks devices for debugging and developing purposes. The following commands are used to configure jtag\_usb utility:

```
sudarsan@south-asia:/var/www$ ls /dev/ttyUSB*
/dev/ttyUSB0 /dev/ttyUSB1 /dev/ttyUSB2
sudarsan@south-asia:/var/www$ sudo rmmmod ftdi_sio
sudarsan@south-asia:~$ sudo mkdir jtag
sudarsan@south-asia:~$ cd jtag/
sudarsan@south-asia:~/jtag$ sudo wget http://svn.gateworks.com/jtag/linux/
x86/jtag_usbv4
sudarsan@south-asia:~/jtag$ sudo chmod 777 jtag_usbv4
sudarsan@south-asia:~/jtag$ sudo ./jtag_usbv4
```

#### 2.2 Bootloader

The entire bootloader can be updated via JTAG using the Gateworks JTAG dongle and the Linux jtag\_usbv4 software:

```
sudo rmmod ftdi_sio  
sudo jtag_usbv4 -p u-boot_spl.bin
```

The u-boot.img can be updated from u-boot using the command:

```
tftp ${loadaddr} u-boot.img && mmc erase 0x8a 0x500 && mmc write  
${loadaddr} 0x8a 0x500
```

## 2.3 Building images

Getting the source code

```
git clone https://github.com/Gateworks/openwrt/ gateworks-openwrt -b 16.02  
cd gateworks-openwrt
```

To build image:

```
make -C gateworks/ imx6
```

OpenWrt can be customized by running the command:

```
make menuconfig
```

In this new window, you can select/deselect packages you want installed. If kernel customization is required, use the command:



```
make kernel_menuconfig
```

Once customization complete, a simple

```
make -j8 V=s
```

will re-run the make command to re-create the rootfs.

Often the error will be reported at the end of the build. However, the error will have actually occurred earlier on. Scroll up in the logs and look for an error. Typically it is from a package or dependency that was not able to be downloaded. To achieve better debugging information after a failure, re-run the build with the following command:

```
make -j1 V=s
```

or

```
make -j1 V=99
```

To delete the contents of the directories /bin and /build\_dir the following command used:


```
make clean
```

The command

```
make dirclean
```

deletes contents of the directories /bin and /build\_dir and additionally /staging\_dir and /toolchain (=the cross-compile tools) and /logs. Dirclean is the basic "Full clean" operation.

Figure 2.1: menuconfig window



## 2.4 .config files

In theory there are 2 separate .config files. One is the Gateworks .config in the folder:

```
gateworks/configs/imx6/.config
```

and the other is the default OpenWrt .config in the folder:

```
gateworks-openwrt/.config
```

When the first build is run using the Makefile

```
make -C gateworks/ imx6
```

This basically copies the gateworks .config and overwrites the default .config.

Then, when the *make menuconfig* is done, it is now only modifying the default

location `.config` in the main `gateworks-openwrt` directory.

The *diff* command can be used to compare two `.config` files and find the packages missing. It can be used as an useful tool for debugging and detecting the package which causes error.

## 2.5 TFTP server

The TFTP server used is `atftpd`. For installing `atftpd` the command used is:

```
sudo apt-get install atftpd
```

To Modify the config file:

```
USE_INETD=false  
OPTIONS="--tftpd-timeout 300 --retry-timeout 5 --port=69  
--maxthread 100 --verbose=7 /tftpboot"
```

`tftpboot` directory's permission and ownership is modified using the command:

```
sudo mkdir /tftpboot  
sudo chmod -R 777 /tftpboot  
sudo chown -R nobody /tftpboot
```

To start and restart the service:

```
sudo /etc/init.d/atftpd restart
```

To confirm the service is running, navigate to the tftpboot folder and use the command:

```
ps -aef | grep atftpd
```

## 2.6 Firmware Installation via TFTP

Ventana board is connected to the network using ethernet cable. ipaddress and serverip are set in uboot (boot the board and break into the bootloader command line on the serial console):

```
setenv ipaddr 10.116.65.191  
setenv serverip 10.116.65.124
```

ipaddress is set as 10.116.65.191 and serverip as 10.116.65.124.

Set the image to be burnt into the board using the command:

```
setenv image_rootfs gateworks-imx6-ventana-squashfs-nand_normal.ubi
```

Save environment variables:

```
saveenv
```

Run the nand\_update script:

```
run nand_update
```

boot:

```
boot
```

To reset the bootloader variables, the following commands are used:

```
env default -f -a
```

```
saveenv
```

```
reset
```

### **2.6.1 Power cycle**

Power cycling the board sometimes helps to solve the errors arising during booting of customized image.

To power cycle the board, first remove the small coin cell battery on the board (be sure the main board power is unplugged before removing the battery).

Plug the power cable back in and unplug it. Keep repeating it 5 times while watching the serial console.

### **2.6.2 Network configuration**

When the boot process is complete, the following commands can be used to connect the board to the network:

```
ifconfig eth0 192.168.1.1 netmask 255.255.255.0
```

```
ifconfig br-lan 10.116.65.191 netmask 255.255.255.0
```

```
route add default gw 10.116.65.1 netmask 0.0.0.0
```

```
ping 10.116.65.124
```

## CHAPTER 3

### Dynamic Voltage and Frequency Scaling

Modern processors allow their core clocks to be scaled in order to trade-off performance vs power or simply to save power when performance is not needed. This is referred to as 'Dynamic Frequency Scaling'. In some cases processors also allow you to scale the core voltages down when using lower clock-speeds which is referred to as 'Dynamic Voltage Scaling'.

Governors are kernel models that can drive CPU core frequency/voltage operating points based on an algorithm. Currently the following governors can be used:

1. performance - sets the frequency statically to the highest available CPU frequency
2. powersave - sets the frequency statically to the lowest available CPU frequency
3. userspace - set the frequency from a userspace program
4. ondemand - adjust based on utilization
5. conservative - adjust based on utilization but be a bit more conservative by adjusting gradually


To show the governor for cpu0:

```
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
```

To show available frequencies (in MHz) for cpu0:

```
cat /sys/devices/system/cpu/cpu0/cpufreq/scaling_available_frequencies
```

Figure 3.1: Processor usage



Conservative governor can be set for a good mix of power-saving and performance

```
echo conservative > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
```

Set to lowest power mode using the powersave governor:

```
echo powersave > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
```

Set to highest performance mode using the performance governor:

```
echo performance > /sys/devices/system/cpu/cpu0/cpufreq/scaling_governor
```

# CHAPTER 4

## Interrupt Steering

The 'affinity' of an interrupt handler can be get or set via

```
/proc/irq/<interrupt>/smp_affinity
```

which is a bitmask of what CPU cores the interrupt handler can run on. By default the affinity for each handler is set to allow all available cores (ie for a dual-core system a value of 3 means bit0 (CPU0) and bit1 (CPU1) are both set). If you want a particular interrupt handler to always occur on a specific CPU you can change that bitmask. To see what interrupt handlers are configured and what interrupt they are on look at /proc/interrupts.

```
root@OpenWrt:/# cat /proc/interrupts
```

	CPU0	CPU1				
16:	18108	13485	GIC	29	Edge	twd
17:	0	0	GPC	55	Level	i.MX Timer Tick
18:	28166	0	GPC	13	Level	mxs-dma
19:	7118	0	GPC	15	Level	bch
20:	0	0	GPC	115	Level	1200000.hdmi
24:	0	0	GPC	26	Level	2020000.serial
25:	0	0	GPC	46	Level	2028000.ssi
37:	0	0	gpio-mxc	4	Edge	gsc
59:	0	0	gpio-mxc	26	Edge	pps.-1



237:	0	0	gpio-mxc	0	Edge	2198000.usdhc cd
272:	0	0	GPC	49	Level	imx_thermal
283:	0	0	GPC	2	Level	sdma
284:	0	0	GPC	43	Level	2184000.usb
285:	0	0	GPC	40	Level	2184200.usb
286:	14292	0	GIC	150	Level	2188000.ethernet
287:	0	0	GIC	151	Level	2188000.ethernet
288:	0	0	GPC	24	Level	mmc0
289:	63	0	GPC	36	Level	21a0000.i2c
290:	0	0	GPC	37	Level	21a4000.i2c
291:	299	0	GPC	38	Level	21a8000.i2c
293:	1435	0	GPC	27	Level	21e8000.serial
294:	0	0	GPC	30	Level	21f4000.serial
299:	0	0	gsc	0	Edge	button
300:	0	0	gsc	1	Edge	key-erased
301:	0	0	gsc	2	Edge	eeeprom-wp
303:	0	0	gsc	4	Edge	0-0023
304:	0	0	gsc	5	Edge	tamper
306:	0	0	gsc	7	Edge	button-held
307:	0	0	pca953x	0	Edge	gpio_keys
323:	0	0	IPU	457	Edge	(null)
324:	4	0	IPU	451	Edge	(null)
325:	36904	0	IPU	23	Edge	imx_drm
326:	0	0	IPU	28	Edge	imx_drm
327:	2	0	GIC	137	Level	2101000.jr0
328:	0	0	GIC	138	Level	2102000.jr1

IPI0:	0	0	CPU wakeup interrupts
IPI1:	0	0	Timer broadcast interrupts
IPI2:	2960	17320	Rescheduling interrupts
IPI3:	0	0	Function call interrupts
IPI4:	94	1276	Single function call interrupts
IPI5:	0	0	CPU stop interrupts
IPI6:	0	0	IRQ work interrupts
IPI7:	0	0	completion interrupts
Err:	0		

root@OpenWrt:/#

# APPENDIX A

## Loading Image

```
root@OpenWrt:/# reboot
```

```
root@OpenWrt:/#
```

```
U-Boot SPL 2015.04-gcc7a886 (Dec 17 2015 - 10:27:21)
```

```
Booting from NAND
```

```
PMIC: LTC3676
```

```
NAND : 256 MiB
```

```
U-Boot 2015.04-gcc7a886 (Dec 17 2015 - 10:27:21)
```

```
CPU: Freescale i.MX6DL rev1.2 at 792MHz
```

```
CPU: Industrial temperature grade (-40C to 105C) at 56C
```

```
Reset cause: WDOG
```

```
WDOG1 Reset cause: SFTW
```

```
WDOG2 Reset cause: POR
```

```
I2C: ready
```

```
DRAM: 512 MiB
```

```
PMIC: LTC3676
```

```
NAND: 256 MiB
```

```
MMC: FSL_SDHC: 0
```

```
No panel detected: default to HDMI
```

```
Display: HDMI (1024x768)
```

```
In: serial
```

```
Out: serial
```

```
Err: serial
```

Gateworks Corporation Copyright 2014

Model: GW5200-C1

MFGDate: 03-31-2015

Serial:663022

GSC: v46 0xd50b WDT:disabled board temp at 46C

RTC: 1457646044

DI00: GPIO1\_I016 (gpio-16)

DI01: GPIO1\_I019 (gpio-19)

DI02: GPIO1\_I017 (gpio-17)

DI03: GPIO1\_I020 (gpio-20)

RS232: enabled

Net: FEC [PRIME], usb\_ether

Error: usb\_ether address not set.

Hit any key to stop autoboot: 0

Ventana >

Ventana > setenv ipaddr 10.116.65.191

Ventana > setenv serverip 10.116.65.124

Ventana > setenv image\_rootfs gateworks-imx6-ventana-squashfs-  
nand\_normal.ubi

Ventana > saveenv

Saving Environment to NAND...

Erasing redundant NAND...

Erasing at 0x10800000 -- 100% complete.

Writing to redundant NAND... OK

Ventana > run nand\_update

Updating NAND from 10.116.65.124:gateworks-imx6-ventana-squashfs-

nand\_normal.ubi...

Using FEC device

TFTP from server 10.116.65.124; our IP address is 10.116.65.191

Filename 'gateworks-imx6-ventana-squashfs-nand\_normal.ubi'.

Load address: 0x12000000

Loading: #####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

#####

```

#####
#####
#####
#####

13.9 MiB/s

done

Bytes transferred = 23068672 (16000000 hex)

NAND erase.part: device 0 offset 0x1100000, size 0xef00000

Erasing at 0xffe0000 -- 100% complete.

OK

NAND write: device 0 offset 0x1100000, size 0x1600000

23068672 bytes written: OK

Ventana > boot

Attempting usb boot...

starting USB...

USB0: Port not available.

USB1: USB EHCI 1.00

scanning bus 1 for devices... 1 USB Device(s) found

    scanning usb for storage devices... 0 Storage Device(s) found

    scanning usb for ethernet devices... 0 Ethernet Device(s) found

USB device 0: unknown device

** Bad device usb 0 **

** Bad device usb 0 **

Attempting mmc boot...

MMC: no card present

MMC: no card present

```

```
** Bad device mmc 0 **

MMC: no card present

** Bad device mmc 0 **

Attempting sata boot...

** Bad device size - sata 0 **

** Bad device size - sata 0 **

Attempting flash boot...

UBI: attaching mtd1 to ubi0

UBI: scanning is finished

UBI: volume 2 ("rootfs_data") re-sized from 9 to 1597 LEBs

UBI: attached mtd1 (name "mtd=2", size 239 MiB) to ubi0

UBI: PEB size: 131072 bytes (128 KiB), LEB size: 126976 bytes

UBI: min./max. I/O unit sizes: 2048/2048, sub-page size 2048

UBI: VID header offset: 2048 (aligned 2048), data offset: 4096

UBI: good PEBs: 1912, bad PEBs: 0, corrupted PEBs: 0

UBI: user volume: 3, internal volumes: 1, max. volumes count: 128

UBI: max/mean erase counter: 1/0, WL threshold: 4096,

image sequence number: 845547390

UBI: available PEBs: 0, total reserved PEBs: 1912,

PEBs reserved for bad PEB handling: 40

Loading file '/6x_bootscript-ventana' to addr 0x12000000

  with size 2423 (0x00000977)...

Done

## Executing script at 12000000

Gateworks Ventana OpenWrt Boot script v1.00

Using dtype from env: nand
```

```
Booting from NAND...

mtdparts:mtdparts=nand:16m(uboot),1m(env),239m(ubi)

Loading file '/uImage' to addr 0x10800000 with size 1536408 (0x00177198)...

Done

** File not found /imx6dl-gw5200-c1.dtb **

** File not found /imx6dl-gw5200.dtb **

Loading file '/imx6dl-gw52xx.dtb' to addr 0x18000000 with size
34293 (0x000085f5)...

Done

Loaded DTB from /imx6dl-gw52xx.dtb

## Booting kernel from Legacy Image at 10800000 ...

   Image Name:   ARM OpenWrt Linux-4.4
   Image Type:   ARM Linux Kernel Image (uncompressed)
   Data Size:    1536344 Bytes = 1.5 MiB
   Load Address: 10008000
   Entry Point:  10008000
   Verifying Checksum ... OK

## Flattened Device Tree blob at 18000000

   Booting using the fdt blob at 0x18000000

EHCI failed to shut down host controller.

   Loading Kernel Image ... OK

   Using Device Tree in place at 18000000, end 1800b5f4

   Updating MTD partitions...

   Adjusting FDT per EEPROM for gw5200-c1...

   Config LDO-enabled mode

Starting kernel ...
```



Press the [f] key and hit [enter] to enter failsafe mode

Press the [1], [2], [3] or [4] key and hit [enter] to select the debug level

Failed to connect to ubus

Please press Enter to activate this console.

BusyBox v1.24.1 () built-in shell (ash)

```

-----
|          |.-----.-----.-----.| | | |.-----.| | | | | | | | |
|  -   ||  _  |  -__|      ||  |  |  ||  _||  _|
|_____| ||  __|_____|__|__||_____| ||__|  |____|
          |__| W I R E L E S S   F R E E D O M
-----
```

DESIGNATED DRIVER (Gateworks Ventana 16.02@4fba0b9, r48868)

```

-----
* 2 oz. Orange Juice          Combine all juices in a
* 2 oz. Pineapple Juice      tall glass filled with
* 2 oz. Grapefruit Juice     ice, stir well.
* 2 oz. Cranberry Juice
-----
```

root@(none):/#

root@(none):/#

## References

<http://trac.gateworks.com/wiki/OpenWrt/building#StepbyStepInstructions>

<http://trac.gateworks.com/wiki/ventana/openwrt>

<http://trac.gateworks.com/wiki/tftpserver>

[http://trac.gateworks.com/wiki/jtag\\_instructions#CreatingjtagableimagesforVentana](http://trac.gateworks.com/wiki/jtag_instructions#CreatingjtagableimagesforVentana)

<http://trac.gateworks.com/wiki/OpenWrt/Configuration>

<http://trac.gateworks.com/wiki/ventana/power>

<http://trac.gateworks.com/wiki/DVFS>

<http://trac.gateworks.com/wiki/multicoreprocessing>